



Hi3521/Hi3520A/Hi3520D/Hi3515A/Hi3515C U-boot Porting **Development Guide**

Issue **04**

Date **2013-07-31**

Copyright © HiSilicon Technologies Co., Ltd. 2012-2013. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of HiSilicon Technologies Co., Ltd.

Trademarks and Permissions



HISILICON, and other HiSilicon icons are trademarks of HiSilicon Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between HiSilicon and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

HiSilicon Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: <http://www.hisilicon.com>

Email: support@hisilicon.com



About This Document

Purpose

This document describes how to port and burn the U-boot (that is, bootloader of the Hi3521 board) on the Hi3521/Hi3520A/Hi3520D/Hi3515A/Hi3515C board, and how to using ARM debugging tools.

Related Version

The following table lists the product version related to this document.

Product Name	Version
Hi3521	V100
Hi3520A	V100
Hi3520D	V100
Hi3515A	V100
Hi3515C	V100

Intended Audience

This document is intended for:

- Technical support personnel
- Software development engineers

Change History

Changes between document issues are cumulative. Therefore, the latest document issue contains all changes made in previous issues.



Issue 04 (2013-07-31)

This issue is the fourth official release, which incorporates the following changes:

Chapter 2 Porting the U-boot

In section 2.5, the caution is updated.

Issue 03 (2013-06-21)

This issue is the third official release, which incorporates the following changes:

The Hi3515C compilation code is added.

Issue 02 (2013-04-03)

This issue is the second official release, which incorporates the following changes:

Chapter 2 Porting the U-boot

A caution related to the Hi3520D and Hi3515A is added.

Issue 01 (2013-02-28)

This issue is the third official release, which incorporates the following changes:

Chapter 1 Overview

The Hi3520D compilation code is added.

Chapter 2 Porting the U-boot

The Hi3520D compilation code is added.

Chapter 3 Burning the U-boot

In section 3.3.2, the caution "Only the Hi3521 and Hi3520A support the NAND flash" is added.

Issue 00B20 (2012-12-30)

This issue is the second official release, which incorporates the following changes:

Chapter 2 Porting the U-boot

In section 2.2, the command for compiling the U-boot is modified.

Issue 00B10 (2012-06-30)

This issue is the first official release, which incorporates the following changes:

Chapter 2 Porting the U-boot

In section 2.5, the final image name is changed, ensuring that the image name is the same as that in the SDK.

Chapter 4 Using ARM Debugging Tools

Figure 4-1 to Figure 4-6 are changed.



Issue 00B02 (2012-06-08)

This issue is the second draft release, which incorporates the following changes:

Chapter 2 Porting the U-boot

In section 2.1, the models of the peripherals on the Hi3521 board are changed.

In section 2.3, the compilation toolchain is changed from arm-hisivX00-linux- to arm-hisiv100nptl-linux- and arm-hisiv200-linux-.

Issue 00B01 (2012-04-20)

This issue is the first draft release.



Contents

1 Overview.....	1
1.1 Description	1
1.2 U-boot Directory Structure.....	1
2 Porting the U-boot.....	3
2.1 Overview	3
2.2 Compiling the U-boot.....	3
2.3 Configuring the DDR	4
2.4 Configuring Pin Multiplexing	4
2.5 Generating the Final U-boot Image.....	4
3 Burning the U-boot.....	5
3.1 Overview	5
3.2 Burning the U-boot by Using the BOOTROM	5
3.3 Burning the U-boot to Two Types of Flash Memories	5
3.3.1 Burning the U-boot to the SPI Flash	5
3.3.2 Burning the U-boot to the NAND Flash	6
4 Using ARM Debugging Tools.....	7
4.1 Overview	7
4.2 ARM Debugging Tools	7
4.2.1 RealView -ICE Simulator	7
4.2.2 RealView Debugger4.0	7
4.3 Usage Guidelines	8



Figures

Figure 4-1 RealView Debugger	8
Figure 4-2 Connect to Target window	9
Figure 4-3 Choosing the RealView-ICE	10
Figure 4-4 Information box 1 of the RealView Debugger	11
Figure 4-5 Information box 2 of the RealView Debugger	12
Figure 4-6 Connect to A9	13



Tables

Table 1-1 Main directory structure of the U-boot.....	1
--	---



1 Overview



NOTE

The Hi3521 is used as an example when the conditions apply to the Hi3521, Hi3520A, Hi3520D, Hi3515A, and Hi3515C. Their differences are separately described.

1.1 Description

The bootloader of the Hi3521 board uses the U-boot. When the types of the selected peripheral components are different from the types of the components on the board, you need to modify the U-boot configuration file including the information about memory configuration and pin multiplexing.

1.2 U-boot Directory Structure

[Table 1-1](#) shows the main directory structure of the U-boot. For details, read the **readme** file in the **U-boot** folder.

Table 1-1 Main directory structure of the U-boot

Directory	Description
arch	Indicates the code of the chip architecture and the entry code of the U-boot.
board	Indicates the code of boards, such as the memory driver code.
board/godarm/	Indicates the code of HiSilicon boards.
lib_XXX	Indicates the code of architecture, such as the common code of ARM and microprocessor without interlocked pipeline stages (MIPS) architecture.
include	Indicates header files.
include/configs	Indicates the configuration files of boards.
common	Indicates the implementation files of functions or commands.



Directory	Description
arch	Indicates the code of the chip architecture and the entry code of the U-boot.
drivers	Indicates the driver code of Ethernet ports, flash memories, and serial ports.
net	Indicates the implementation files of network protocols.
fs	Indicates the implementation files of file systems.



2 Porting the U-boot

2.1 Overview

The following are the peripherals on the Hi3521 board:

- Double-data rate (DDR) synchronous dynamic random access memory (SDRAM): K4B2G1646C-HCK0
- NAND flash: TC58NVG1S3ETA00
- Serial peripheral interface (SPI) flash: FL128PIFL121QQ030

If other peripherals are used, the corresponding board can work properly only after you modify the configuration sheet in **osdrv/ tools/pc_tools/uboot_tools/** of the SDK.

2.2 Compiling the U-boot

After preceding operations are complete, you can compile the U-boot by running the following commands:

```
make ARCH=arm CROSS_COMPILE=arm-hisivXXX-linux- godarm_config //Select the  
Hi3521  
make ARCH=arm CROSS_COMPILE=arm-hisivXXX-linux- godcare_config //Select  
Hi3520A  
make ARCH=arm CROSS_COMPILE=arm-hisivXXX-linux- hi3520d_config //Select the  
Hi3520D/Hi3515A
```

If the compilation is successful, the **u-boot.bin** file is generated in the **U-boot** folder.

NOTE

The **CROSS_COMPILE** parameter indicates the tool chain. In this document, the **CROSS_COMPILE** = **arm-hisiXXX-linux-** parameter indicates the following two situations:

- Hi35xx_V100R001C01SPCxxx corresponds to uclibc. If the uclibc tool chain is used, the **CROSS_COMPILE** parameter is set to **arm-hisiv100nptl-linux-**.
- Hi35xx_V100R001C02SPCxxx corresponds to glibc. If the glibc tool chain is used, the **CROSS_COMPILE** parameter is set to **arm-hisiv200-linux-**.



CAUTION

The **u-boot.bin** file is not the final u-boot image.

2.3 Configuring the DDR

In Windows, open the configuration sheet in **osdrv/ tools/pc_tools/uboot_tools/** of the SDK. If different DDR SDRAM is used, modify the contents on the tab pages of the configuration sheet based on the component features.

2.4 Configuring Pin Multiplexing

If the pin multiplexing relationship changes, modify the contents on the related tab page of the configuration sheet.

2.5 Generating the Final U-boot Image

Perform the following steps:

- Step 1** Save settings after modifying the configuration sheet.
- Step 2** Click **Generate reg bin file** on the first tab page of the configuration sheet to generate the temporary file **reg_info.bin**.
- Step 3** Copy **u-boot.bin** (it is generated after the U-boot is compiled) and **reg_info.bin** to **osdrv/uboot/ uboot_tools** of the SDK, and run the following command:

```
mkboot.sh reg_info.bin u-boot-hi3521_930MHz.bin
```

u-boot-hi3521_930MHz.bin is the final u-boot image that can run on the board.

----End



CAUTION

To create U-boot images of the Hi3520D, Hi3515A, and Hi3515C, generate two temporary files by using Hi3520D, Hi3515A, and Hi3515C configuration sheets, rename the temporary files **reg_info_hi3520d.bin** and **reg_info_hi3515a.bin** respectively, copy **reg_info_hi3520d.bin**, **reg_info_hi3515a.bin**, and compiled **u-boot.bin** to **osdrv/tools/pc_tools/uboot_tools/** of the SDK, and then run **mkboot-hi3520d.sh reg_info_hi3520d.bin reg_info_hi3515a.bin u-boot-hi3520d.bin**. Note that **reg_info_hi3520d.bin** must be before **reg_info_hi3515a.bin** in this command.



A 4800-byte blank zone must be reserved in the U-boot code segment for storing **reg_info_hi3520d.bin** and **reg_info_hi3515a.bin**. Each of them occupies 2400 bytes. The blank zone should not be greater than 4800 bytes due to the limitation of the on-chip RAM. Otherwise, the fastboot cannot be burnt. If a blank zone greater than 4800 bytes is required, you are advised to burn a U-boot image that is less than or equal to 4800 bytes by using the fastboot tool, and then burn a U-boot image greater than 4800 bytes over the network to replace the previously burnt one.

To combine **reg_info.bin** of the Hi3520D, Hi3515A, or Hi3515C with the U-boot image, you need to comment out the macro **ENABLE_HI3520D_BLANK** or **ENABLE_HI3515A_BLANK** in **./include/configs/hi3520d.h** of the U-boot.

The **REG_INFO_BLANK_SIZE** macro specifies the size of the blank zone reserved for the temporary file (**reg_info_XXX.bin**). The default value of **REG_INFO_BLANK_SIZE** is 2400, and you can change it.

To combine more temporary files with the U-boot image, perform the following steps:

Step 1 Modify the code in rows 54–61 in **./arch/arm/cpu/hi3520d/start.S** as follows:

```
__blank_zone_start:
#ifdef ENABLE_HI3520D_BLANK
.fill REG_INFO_BLANK_SIZE,1,0    /*Blank zone*/
#endif
#ifdef ENABLE_HI3515A_BLANK
.fill REG_INFO_BLANK_SIZE,1,0    /*Blank zone*/
#endif
/*Add new blank zones.*/
__blank_zone_end:
```

Step 2 Modify **mkboot-hi3520d.sh** in **osdrv/tools/pc_tools/uboot_tools/** as follows:

```
dd if=$1 of=../fb2 bs=2400 conv=sync
dd if=$2 of=../fb3 bs=2400 conv=sync
/*You can add commands similar to the preceding two commands.*/
dd if=./u-boot.bin of=../fb4 bs=1 skip=4864 /*4864 = 64 + Size of all blank zones*/
cat fb1 fb2 fb3 fb4 > $3
----End
```



3 Burning the U-boot

3.1 Overview

If the U-boot has run on the board to be ported, you can update the U-boot by connecting the board to the server over the serial port or Ethernet port.

If the U-boot is burnt for the first time, burn the U-boot by using the RealView Development Suite (RVDS) tool over the Ethernet port. According to the chip feature, you must download the scripts for initializing the DDR and chip to the board by using the RVDS tool. The initialization scripts are provided in the Hi3521 SDK. When different DDRs are used, the Hi3521 can work properly only when the initialization scripts are reconfigured.

3.2 Burning the U-boot by Using the BOOTROM

For details, see the *Fastboot Burning Tool Application Notes*

3.3 Burning the U-boot to Two Types of Flash Memories

3.3.1 Burning the U-boot to the SPI Flash

Perform the following steps:

Step 1 Run the following commands in the HyperTerminal after the U-boot runs in the memory:

```
hisilicon# mw.b 0x82000000 ff 0x100000 /*Set the DDR value of all Fs.*/
hisilicon# tftp 0x82000000 u-boot-hi3521_930MHz.bin /*Download the U-boot to
the DDR.*/
hisilicon# sf probe 0 /*Detect and initialize the SPI
flash.*/
hisilicon# sf erase 0x0 0x100000 /*Erase 1 MB capacity of the SPI
flash.*/
hisilicon# sf write 0x82000000 0x0 0x100000 /*Write the U-boot from the DDR
to the SPI flash.*/
```



Step 2 Restart the system. The U-boot is burnt successfully.

----End

3.3.2 Burning the U-boot to the NAND Flash



CAUTION

Only the Hi3521 and Hi3520A support the NAND flash.

Perform the following steps:

Step 1 Run the following commands in the HyperTerminal after the U-boot runs in the memory:

```
hisilicon# nand erase 0 100000          /*Erase 1 MB capacity of the NAND
flash.*/
hisilicon# mw.b 0x82000000 ff 100000    /*Set the DDR value to all Fs.*/
+hisilicon# tftp 0x82000000 u-boot-hi3521_930MHz.bin /*Download the
U-boot to the DDR.*/
hisilicon# nand write 0x82000000 0 100000 /*Write the U-boot from the DDR
to the NAND flash.*/
```

Step 2 Restart the system. Then the U-boot is burnt successfully.

----End



4 Using ARM Debugging Tools

4.1 Overview

This chapter describes how to use the following tools to debug the ARM processor:

- [RealView -ICE Simulator](#)
- [RealView Debugger4.0](#)

4.2 ARM Debugging Tools

4.2.1 RealView -ICE Simulator

The RealView-ICE simulator is a high-performance real-time simulator. It supports the processor with the ARM core (such as ARM7, ARM9 Xscale, ARM11, or ARM_CORTEXA9) and is essential for the ARM-based development and debugging.

The RealView-ICE simulator has the following features:

- Supports the debugging of the ARM core chips with the embedded ICETM logic and the debugging of the developing chips with the ARM cores including ARM7, ARM710, ARM720, ARM740, ARM9, ARM920, ARM10, and ARM11.
- Supports the power supplies from 1.8 V to 5 V in the target system.
- Allows you to modify the values of registers and memories, set hardware breakpoints, and add inspection windows over the Ethernet port.
- Allows you to save user-defined data and palettes at the beginning or at the end of binary files.

4.2.2 RealView Debugger4.0

The RealView Debugger4.0 is a software development debugging tool provided by ARM. This tool is designed to develop high-quality ARM code for software developers. The RealView Debugger4.0 has the following functions:

- Allows you to set simple or complicated breakpoints.
- Provides inspection windows for checking the change of variables.
- Supports all the new and existing ARM processors.



- Supports the enhanced Windows management mode.
- Provides the enhanced functions of displaying, modifying, and editing data.
- Provides comprehensive command-line interfaces (CLIs).


4.3 Usage Guidelines

Before debugging programs or burning the U-boot to the board by using the Multi-ICE server, you must run the Multi-ICE server to locate the ARM chip connected to the hardware, and start the RealView Debugger.

For details about how to use ARM debugging tools, see the documents provided by ARM. The following is an example using the RealView Debugger. Perform the following steps:

- Step 1** Install the ARM developer Suite v4.0. It is the RealView Debugger setup program provided by ARM. Before installation, read relevant documents provided by ARM.
- Step 2** Run the RealView Debugger, as shown in [Figure 4-1](#).

Figure 4-1 RealView Debugger





- Step 3** Click  to connect the simulator to the RealView-ICE. The window shown in [Figure 4-2](#) is displayed.




Figure 4-2 Connect to Target window



Step 4 Click **Add** after **RealView-ICE**, locate a simulator, and connect it to the RealView-ICE, as shown in [Figure 4-3](#).



Figure 4-3 Choosing the RealView-ICE



Step 5 Click **Auto Configure** shown in [Figure 4-4](#). If the A9 processor is detected, the window shown in [Figure 4-5](#) is displayed.



Figure 4-4 Information box 1 of the RealView Debugger








Figure 4-5 Information box 2 of the RealView Debugger



Step 6 Choose **File > Save** to save settings, click **Cortex-A9_0**, and choose **Connect** from the shortcut menu, as shown in [Figure 4-6](#).



Figure 4-6 Connect to A9



----End